

Installing Mailbox on #6 Post

The mailbox mounts on the #6 post have the threads inset into the mount itself. Imperial ships this particular post with the bolts already threaded into the mounts.

- 1 Remove all (4) bolts from the post mounts.

- 2 Open the mailbox door and align the holes in the mailbox with the threads on the post mounts.



- 2 Open the mailbox door and align the holes in the mailbox with the threads on the post mounts.
- 3 Insert each bolt through the holes in the mailbox and into the post mounts. Hand tighten so that the mailbox is securely fastened to the post.
- 4 Adjust the level of the mailbox and then tighten the bolts with a screwdriver.

