

## IMPORTANT NOTE:

Customers should verify that there are no water or electrical lines in area before digging.

Generally, street signs are installed at a height of 7 feet from road surface to bottom of traffic sign. Contact local municipality for installation regulations.

## To Facilitate Installation:

Dig a hole approximately 24 inches deep for sign with 24 inch (or smaller) back plate, 30 inches for 30 inch (or larger) back plate using post hole digger or shovel.

- 1 Assemble street sign, attaching frame(s) and backplate(s).
- 2 Place street sign into hole, verify correct positioning of sign direction.
- 3 While keeping base above the ground, fill hole with concrete.
- 4 Slide base to ground level, tighten screws.
- 5 Ensure sign pole is level. Do not handle pole for 24 hours.



**APPROVED**

USPS STD 7B Approved Mailboxes Are Required for all Residential Developments.

